

FIG.1




FIG.2

Step	Direction		Message
	MOBILE TERMINAL	TEST APPARATUS	
0			
1		←---	PAGING TYPE1(PCCH)
2		---->	RRC CONNECTION REQUEST (CCCH)
3		←---	RRC CONNECTION SETUP (CCCH)
4		---->	RRC CONNECTION SETUP COMPLETE (DCCH)
5		---->	PAGING RESPONSE
6		←---	ACTIVATE RB TEST MODE
7		---->	ACTIVATE RB TEST MODE COMPLETE
8		←---	RADIO BEARER SETUP
9		---->	RADIO BEARER SETUP COMPLETE
10		←---	CLOSE UE TEST LOOP (DCCH)
11		---->	CLOSE UE TEST LOOP COMPLETE
			UNDER TEST
12		←---	OPEN UE TEST LOOP
13		---->	OPEN UE TEST LOOP COMPLETE
14		←---	RRC CONNECTION RELEASE
15		---->	RRC CONNECTION RELEASE COMPLETE

FIG.3